


■ Outline

A simplified I/O BOX enables to interlock external devices such as switch, LED lights and buzzer by connecting the driver BLG-BC2 Series.

■ Part Names



● Electric Driver Interlock LED

1. ST (ON from start to stop)
2. T.UP (ON when the driver clutched out)
3. WORK-Err (ON when work pieces are not set)
4. WORK-ON/OFF (presence/absence of work -piece)
5. FOR (ON during normal rotation)
6. REV (ON during reverse rotation)
7. PASS (ON when screw-fastening errors did not occur)
8. Fail (ON when screw-fastening errors occurred)
9. COMP (ON after cycle complete.)


● Switches on the Front Panel

1. RESET1
2. RESET2
3. Dr-SW
(BLG-BC2 can be forcibly turned off.)
When this switch is OFF,
BC2 is OFF,
LED "LOCK" is ON.
4. DSW1 (Reference 1)

● External Connection

- Turn ON after all the connections are completed.
1. BLG-BC2-3010 Connector
 2. I/O Port (Reference 2)
 3. 6-pin Metal Connector (2 pieces)
Right -> Power Supply for T-45BL or T-70BL
Left -> BLG-BC2 screwdriver

■ External Dimension Drawing



■ DSW ON/OFF Operational Conditions (Reference Table 1)

DSW1 #	Setting name	Contents (DSW1)	
		ON	OFF
1	Work-piece Set	BC2 is operable regardless of presence /absence of work-piece (WORK LED is turned on)	BC2 can be operable/inoperable using the Work –piece set signals output by a switch, sensor, etc. (WORK LED is turned off)
2	Reset BC2 after a screw-fastening error (Fail)	ON: the count is returned to the value just before the error occurred	OFF: reset, the count is returned to the default value.
3	Set up mode buttons on BC2	All BC2 set up mode buttons are locked. BC2 set up modes cannot be changed with the buttons on the BC2. LED "M" light on the BC2 is ON.	All BC2 set up mode buttons are unlocked. BC2 set up modes can be changed with the buttons on the BC2. LED "M" light on the BC2 is OFF.
4	Operation of screwdriver after batch count complete	BC2 is not operable from batch count complete until a new work-piece is set.	BC2 is operable after batch count complete.
5	IO Pro1 Buzzer	Buzzer works upon PASS, Fail and cycle complete.	Buzzer does not work.
6	Operation after an error (Fail)	BC2 is still enabled upon Fail.	BC2 becomes disabled upon Fail. Release (* Note: Same as DSW1-2)
7	NC		
8	NC		

(Note) The default factory setting is "ON" for DSW1 #1 and 6.

[Precaution]

■ DSW1 setting must be done when the I/O BOX is powered off.

● DSW1 #1

should be "OFF" when an external work-piece set is used through the I/O Port.

● DSW1 #2

* When DSW1 #6 are "OFF"

BC2 is not disabled when the Fail LED is on. Press the RESET button on the front panel of I/O BOX to release.

* RESET buttons sequence

1. RESET1 -> For turning off the buzzer (BC2 is not enabled at this point.)
After confirming everything is ready to restart operation, press RESET2 button.
2. RESET2 -> BC2 becomes enabled.

* When DSW1 #5 are "ON", #6 are "OFF"

When Fail LED turns on and buzzer sounds, BC2 becomes disabled. Press the RESET buttons to release.

* Order to push the RESET buttons

1. RESET1 -> For turning off the buzzer (BC2 is still disabled at this point.)
After confirming everything is ready to restart operation, press RESET2 button.
2. RESET2 -> BC2 becomes enabled.

● DSW1 #4

* When DSW1-4 is ON, DSW1-1 needs to be "OFF" and use Work-piece set signals by a switch, sensor, etc.

● DSW1 #5

* External buzzers can be used by connecting to the I/O Port.


■ Pin Configuration of the I/O Port Connector (Reference 2)

(Please share connection with GND.) HIF3BA Type 40-pin


Connection direction		Pin numbers and names	
		Pin numbers	Names
GND		22, 23, 24, 25, 36, 37	
Low active input (Operable on the input signal at Low level.)		26, 27	Work-piece Set
		32, 33	RESET1
		34, 35	RESET2
Open collector output		11	PASS/COMP (revolving lights, etc.)
		12	T-UP/COMP (revolving lights, etc.)
		13	Fail/COMP (revolving lights, etc.)
		15	Buzzer (DSW1 interlock)
		20	PASS
		21	Fail
For connecting devices such as PC (RS232C). Refer to "BLG-BC2 communication specifications"		38	RXD
		39	GND
		40	TXD

How to use Low Active Internal Circuit

- The voltage should be less than 0.3V at Low
- The voltage should be less than 30V for pull-up resistor of an external voltage supply



The reference structural outline when an external buzzer is installed and interlocks with the I/O BOX buzzer is externally installed (External power supply is needed for the external buzzer.)



■ Other Specifications

★ Specifications	
Consumption current 30V/40mA (Please use the HIOS power supply T-BL series dedicated to HIOS electric screwdriver)	
Open collector output (max. 40V/40mA)	
★ Items included in the package	
BLG-IO-Pro1: 1 unit	40-pin connector (250mm) : 1pc
6-pin driver cord 2m: 1pc	BLG-IO-Pro1 Operation Manual: 1copy

* The BLG-BC2 I/O Cable is optional and not included in the package.