Current-Controlled Screwdriver **DCD-40L (115W)**

Instruction Manual

ET-A070 19A

HIOS Inc.

Introduction

This manual describes the touch panel operations and functions of the screwdriver.

Abbreviations and terminology

The abbreviations and terminology used in this manual are defined in the table below.

Abbreviation/terminology	Definition
SVC or controller	SV-NET Controller
SVD or driver	SV-NET compatible driver
Servo motor or motor	AC servo motor

Contents

Introduction	2
Abbreviations and terminology	2
Contents	
1. Startup screen	5
2. Main screen	6
3. [Program Preview] screen	7
3.1 Screen display items	7
Screen display items (buttons)	7
Screen display items (numeric values)	
4. [Operate] screen	
4.1 Screen display items	
Screen display items (buttons)	
Screen display items (numeric values, lamps)	
5. [Monitor Operate] screen	
5.1 Screen display items	11
Screen display items (buttons)	11
Screen display items (numeric values)	
Screen display items (lamps)	
6. [Edit] screen	
6.1 Password input	
Screen display items (numeric input)	14
Screen display items (buttons)	
7. [HIOS] setting screen	
7.1 Password input	17
Screen display items (numeric input)	
8. Operation parameters	
Parameter settings for each operation pattern	
Parameter setting range for operation patterns	21
Parameter setting range for special settings	
9. Operation pattern timing charts	
■ Pattern 1	
Pattern 2	
Pattern 3	
■ Pattern 4	
10. Manual/auto mode	
Manual mode	
Auto mode	
11. I/O	
11.1 I/O allocation table	

I/O input signals	31
■ I/O output signals	32
11.2 I/O input signal reception time table	
I/O input signals	32
11.3 I/O input signal sequence	34
Sequence of each input control signal	34
Output status signals	35
11.4 I/O input timing charts	
Timing chart for normal operations when torque judgment is OK	
Timing chart for normal operations when torque judgment is NG	37
Timing chart when emergency stop signal is input	
12. Message window	
Displayed messages	
Message list	43
13. System settings	44
Displaying the system settings screen	44
Checking the screw tightening OK judgment count	44
Checking the total number of screw tightening OK judgments	44
■ You can check the total number of times that the screw tightening OK judgment has been counted	44
14. Button touch operations	45
15. Holding time	46
Holding time setting	46
16. Detailed pattern diagrams	47
Chattering judgment	47
17. Alarms	49
17.1 Error list (motor driver errors)	49
17.3 Error list (SVC errors)	52

1. Startup screen

The title screen is displayed when the touch panel first starts up.

After a few moments, the main window is displayed.



Fig.1-1 Title screen

2. Main screen

On the main screen, select the screen that you want to display.

Touch a button to display the corresponding screen.



Fig.2-1 Main screen

If the external I/O is set to auto operation mode input, operation starts when the external I/O start signal is ON, even while the main window is displayed.

* If the external I/O channel No. and pattern No. are not selected, an operation error (103) occurs.

The [Program Preview] screen and [Edit] screen cannot be opened in auto operation mode.

3. [Program Preview] screen

On the [Program Preview] screen, you can select the tightening operation pattern, load the saved parameters, and check the parameters.



Fig.3-1 [Program Preview] screen (1/2)

CH PTN No No	Torque allowance	Load
	Torque allowance	
	Counter 123tms	Prev Back

Fig.3-2 [Program Preview] screen (2/2)

3.1 Screen display items

Screen display items (buttons)

Screen display button	Description				
Select the channel No. Touch the [▲] button to increase the number, and touch the [▼] to a it. A value from 1 to 8 can be selected.					
PTN No	Select the pattern No. Touch the [▲] button to increase the number, and touch the [▼] to decrease it. A value from 1 to 4 can be selected.				
Load	Load the saved parameters for the combination of channel No. and pattern No. When loading is complete, the [Data loaded] message window is displayed.				
Next	Display the next or previous page to check the parameters.				
Back	Return to the main screen.				

Screen display items (numeric values)

Numeric value	Description			
display item				
Angle 1	Rotation angle setting for temporary tightening. The unit is $^{\circ}$ (degrees).			
(Rotation angle 1)				
Angle 2	Rotation angle setting for loosening. The unit is ° (degrees).			
(Rotation angle 2)				
Angle 3	Rotation angle setting for additional tightening. The unit is ° (degrees).			
(Rotation angle 3)				
Rotation 1	Rotation speed setting for temporary tightening. The unit is rom			
(Rotation speed 1)				
Rotation 2	Rotation speed setting for full tightening, loosening, and additional tightening. The unit is rom			
(Rotation speed 2)				
Trq 1	Torque setting that is applied when switching from temporary tightening to full tightening. The unit is			
(Torque 1)	N.m.			
Trq 2	Limit torque setting for full tightening. The unit is N.m.			
(Torque 2)				
Trq 3	Limit torque potting for tightoning. The unit is N m			
(Torque 3)	Limit torque setting for lightening. The unit is N.m.			
Cycle TM	Time setting for the full set of screw tightening operations. The unit is sec.			
(Cycle time)	An error is displayed if the specified time is exceeded.			
Hold TM (Holding time)	Holding time setting for screw tightening judgment. The unit is ms. * See Chapter 15 "Holding time".			
	Setting range value for when motor torque value judgment is performed in screw tightening judgment.			
(Torque judgment	The unit is ±%.			
(Torque Judgment	Example: When the torque judgment range is $\pm 10\%$ for a torque setting of 1 N.m, the judgment is OK			
range)	if the torque is from 0.9 N.m to 1.1 N.m. * See Chapter 16.			
	Setting for number of times that normal motor torque value is detected, for screw tightening judgment.			
Counter (Torque	The judgment is OK if the number of times that the normal motor torque value is detected is within the			
iudament countor)	range.			
judgment counter)	The judgment is NG if the number of times that the normal motor torque value is detected is outside			
	the range. * See Chapter 16.			

■ [Operate] screen

4. [Operate] screen

On the [Operate] screen, start the screw tightening operations using the parameters that have been set.



Fig.4-1 [Operate] screen

4.1 Screen display items

Screen display items (buttons)

Screen display button		Description	When button is	
		Description	enabled	
			- In manual mode	
			- Before starting	
0.1		Start the screw tightening operation for the specified channel No. and pattern	operation	
	art	No.	- When alarm	
			reset IN (IN 12) is	
			OFF	
St	op	Stop the screw tightening operation while it is being performed.	- In manual mode	
	CCW	[CW] (Clockwise)/[CCW] (Counterclockwise)		
		Select the rotation direction for screw tightening. This setting cannot be changed while screw tightening operation is being	- In manual mode	
		performed.	operation	
		When an error occurs, the [Error No.] and [Error Reset] buttons are		
Eri	ror	displayed.		
Reset		After removing the cause of the error, touch the [Error Reset] button to clear	- Always enabled	
		the error display.		
Ba	ck	Return to the main screen.	- Always enabled	
Rev		[Rev] (Reverse)	- In manual mode	
		The screwdriver rotates in the screw loosening direction while this button is	- Before starting	
		touched.	operation	

Screen display items (numeric values, lamps)

Screen display item		splay item	Description	
CH PTN No No F F		PTN No	The currently selected channel No. and pattern No. are displayed.	
			The start and finish status of the screw tightening operation is indicated.	
Strt		Fin	[Strt] (Start): Lights up while screw tightening operation is being performed.	
			[Fin] (Finish): Lights up for 100 ms after screw tightening operation is complete.	
			The status of the screw tightening operation is indicated.	
			[Tmp] (Temporary tightening): The screw is being temporarily tightened.	
THE	E.u.		[Full] (Full tightening): The temporary tightening operation has finished, and the	
THP		800	screw is being fully tightened.	
			[Add] (Additional tightening): The full tightening operation has finished, and the	
			screw is being additionally tightened.	
			The direction of the screw tightening operation is indicated.	
C W		CCW	[CW] (Clockwise): Screw tightening direction	
	_		[CCW] (Counterclockwise): Screw loosening direction	
			The current mode is indicated.	
Man I Auto		Auto	[Manl] (Manual): Manual mode	
			[Auto] (Auto): Auto mode	
		1 (3 (3	When an error occurs, the [Error No.] and [Error Reset] buttons are displayed.	
Erro NO. <u>123</u>		$\square 23$	The error No. of the current error is displayed.	
			The status of the screw tightening operation is indicated.	
	START OUT		[START OUT]: Lights up while screw tightening operation is being performed.	
		\mathbf{Q}	[FINISH OUT]: Lights up for 100 ms after screw tightening operation is complete.	

5. [Monitor Operate] screen

On the [Monitor Operate] screen, start the screw tightening operations using the parameters that have been set.

Various information about the motor can be checked.



Fig.5-1 [Monitor Operate] screen

5.1 Screen display items

Screen display items (buttons)

Screen display button		Description	When button is enabled
Start		Start the screw tightening operation for the specified channel No. and pattern No.	 In manual mode Before starting operation When alarm reset IN (IN 12) is OFF
Stop		Stop the motor while operation is being performed.	- In manual mode
Manual [Manual]	Auto [Auto]	Switch between manual mode and auto mode. The mode cannot be changed when auto ON is input from the external I/O. * These buttons can be used to switch the mode only while the [Monitor Operate] screen is open. When you return to the main screen, the mode automatically switches to manual mode.	- Before starting operation
[Clockwise]		Select the rotation direction for screw tightening. These buttons are enabled only in manual mode. The direction cannot be changed while the screw tightening operation is being performed.	- In manual mode - Before starting operation
Error Reset		Clear the current error from the error display.	- Always enabled
Back		Return to the main screen.	- Always enabled
Rev] (Reverse)		The screwdriver rotates in the screw loosening direction while this button is touched.	- In manual mode - Before starting operation

■ [Monitor Operate] screen

Screen display items (numeric values)

Screen display item	Description		
CH PTN No No	The currently selected channel No. and pattern No. are displayed.		
Rotation	The motor rotation speed is displayed in units of rpm.		
(Rotation speed)			
Motor trq	The mater terraue is displayed in units of N m		
(Motor torque)			
Angle			
(Rotation angle)	The current rotation angle is displayed in units of ° (degrees).		
Hold time	The holding time for the screw tightening operation is displayed in units of ms.		
(Holding time)	* See Chapter 15 "Holding time".		
Error No.	The error No. of the current error is displayed. For details, see the "Error list" sections.		

Screen display items (lamps)

Screen display item		em	Description	
			The start and finish status of the screw tightening operation is indicated.	
Strt	1000	Fin		[Strt] (Start): Lights up while screw tightening operation is being performed.
				[Fin] (Finish): Lights up for 100 ms after screw tightening operation is complete.
				The status of the screw tightening operation is indicated.
				[Tmp] (Temporary tightening): Temporary tightening is being performed on the
		Full		screw.
Tap	Fu			[Full] (Full tightening): The temporary tightening operation has finished, and full
				tightening is being performed.
			[Add] (Additional tightening): The full tightening operation has finished, and	
				additional tightening is being performed.
				The direction of the screw tightening operation is indicated.
CW		CCW		[CW] (Clockwise): Screw tightening direction
				[CCW] (Counterclockwise): Screw loosening direction
			The status of the screw tightening operation is indicated.	
START FINISH			[START OUT]: Lights up while screw tightening operation is being performed.	
			[FINISH OUT]: Lights up for 100 ms after screw tightening operation is complete.	

[Edit] screen

6. [Edit] screen

Configure the various parameter settings that are necessary for the screw tightening operations.

Configured settings can be saved or loaded for each channel No. and pattern No.

Touch a numeric value input field to enter a value using the numeric keys. For details about each numeric value input field and each button, see the screen display item descriptions below.





1st hold time w/rev	123	ms	Save
Tmp chat period	123	ms	
Tmp chat counter	123	t∎s	Next Back

Fig.6-2 [Edit] setting screen (2/2)

6.1 Password input

A password must be entered in order to display the [Edit] screen.

Touch the numeric keys displayed on the screen to enter the password. (The factory default setting is a four-digit password

{8104}, and a password of up to eight digits can be set.)

Touch the [BS] button to delete the last digit.

Touch the [CLR] button to delete all digits.

Touch the [ENT] button to log in with the password.

When the correct password is entered, the [Edit] screen is displayed. If the password is not correct, a warning message is displayed. If no password is entered for one minute, the main screen is automatically displayed again.

Please Enter Password							
Level 1 or above							
1	2	3	4	5	BS	ENT	
6	7	8	9	0	CLR	ESC	

6.3 Password input screen

■ [Edit] screen

6.2 Screen display items

Screen display items (numeric input)

Numeric input item	Description
Angle 1 (Rotation angle 1)	Rotation angle setting for temporary tightening. The unit is ° (degrees).
Angle 2 (Rotation angle 2)	Rotation angle setting for loosening. The unit is ° (degrees).
Angle 3 (Rotation angle 3)	Rotation angle setting for additional tightening. The unit is ° (degrees).
Rotation 1 (Rotation speed 1)	Rotation speed setting for temporary tightening. The unit is rpm.
Rotation 2 (Rotation speed 2)	Rotation speed setting for full tightening, loosening, and additional tightening. The unit is rpm.
Torque 1 (Torque 1)	Torque setting that is applied when switching from temporary tightening to full tightening. The unit is N.m.
Torque 2 (Torque 2)	Limit torque setting for full tightening. The unit is N.m.
Torque 3 (Torque 3)	Limit torque setting for tightening. The unit is N.m.
Cycle TM	Time setting for the full set of screw tightening operations. The unit is sec.
(Cycle time)	An error is displayed if the specified time is exceeded.
Hold TM (Holding time)	Holding time setting for screw tightening judgment. The unit is ms. * See Chapter 15 "Holding time".
Torque allowance (Torque judgment range)	Setting range value for when motor torque value judgment is performed in screw tightening judgment. The unit is ±%. Example: When the torque judgment range is ±10% for a torque setting of 1 N.m, the judgment is OK if the torque is from 0.9 N.m to 1.1 N.m. * See Chapter 16.
	Setting for number of times that normal motor torque value is detected, for screw tightening judgment.
Counter	The judgment is OK if the number of times that the normal motor torque value is detected is within the
(Torque judgment	range.
counter)	The judgment is NG if the number of times that the normal motor torque value is detected is outside the range. * See Chapter 16.

■ [Edit] screen

Screen display items (buttons)

Screen display button	Description
H≥ ►	Select the channel No. Touch the [▲] button to increase the number, and touch the [▼] button to decrease it. A value from 1 to 8 can be selected.
	Select the pattern No. Touch the [▲] button to increase the number, and touch the [▼] button to decrease it. A value from 1 to 4 can be selected.
Load	Load the saved parameters for the combination of channel No. and pattern No. When loading is complete, the [Data loaded] message window is displayed.
Save	Save the currently configured parameters for the combination of channel No. and pattern No. If parameters have already been saved for the combination, the data is overwritten. When saving is complete, the [Data saved] message window is displayed.
HIOS	Open the screen for configuring special settings that apply to all operation patterns, and settings that are specific to the motor. Since the settings are normally configured by HIOS, a password is required in order to display the screen.
Next	[Next]/[Prev] Display the next or previous page of the [Edit] screen.
Back	Return to the main screen.

7. [HIOS] setting screen

Open the screen for configuring special settings that apply to all operation patterns and to settings that are specific to the motor.

Since the settings are normally configured by HIOS, a password is required in order to display the screen.

Touch a numeric value input field to enter a value using the numeric keys. For details about each numeric value input field and each button, see the screen display item descriptions below.



Fig.7-2 [HIOS] setting screen (2/6)



Fig.7-3 [HIOS] setting screen (3/6)

Reverse stand-by	123	ms	Save
Add angle range	123	<u>_</u> %	Prev
Reverse angle range	123	<u> 1</u> 8	Next
			Back

Fig.7-4 [HIOS] setting screen (4/6)



Fig.7-5 [HIOS] setting screen (5/6)



Fig.7-6 [HIOS] setting screen (6/6)

7.1 Password input

A password must be entered in order to display the [HIOS] setting screen.

Touch the numeric keys displayed on the screen to enter the password. (The factory default setting is an eight-digit password

{81040000}, and a password of up to eight digits can be set.)

Touch the [BS] button to delete the last digit.

Touch the [CLR] button to delete all digits.

Touch the [ENT] button to log in with the password.

When the correct password is entered, the [HIOS] setting screen is displayed. If the password is not correct, a warning message is displayed. If no password is entered for one minute, the main screen is automatically displayed again.

	Please Enter Password								
Le	Level 2 or above								
	1	2	3	4	5	BS	ENT		
	6	7	8	9	0	CLR	ESC		

Fig.7-4 Password input screen

7.2 Screen display items

Screen display items (numeric input)

Numeric input item	Description
1st hold time w/rev (Holding time for first full tightening in operation patterns that include reverse rotation)	Set the holding time for the first full tightening in operation patterns that include reverse rotation. The unit is ms. * See Chapter 15 "Holding time".
Tmp chat period (Chattering judgment period for temporary tightening)	Set the period of one scan in the current chattering judgment for temporary tightening. The unit is ms. * See Chapter 16.
Tmp chat counter (Chattering judgment count for temporary tightening)	Set the number of scans to perform in the current chattering judgment for temporary tightening. The unit is the number of times. * See Chapter 16.
Full/Add – Specified current (Negative current value used for judgment of whether the specified current is reached in full tightening and additional tightening)	This is the parameter setting to use in the calculation of the current for the torque detection judgment, to speed up torque-up detection for full tightening and additional tightening. The specified percentage amount is subtracted from the full tightening and additional tightening current. The unit is -%.
Reverse Speed (Reverse operation speed)	Set the speed of the reverse operation. The unit is rpm.
Reverse Speed (Reverse operation speed) Motor KT (spec) (Motor KT value (specification value))	Set the speed of the reverse operation. The unit is rpm. Set the KT value of the motor that is used. (Refer to the motor specifications.) The unit is N.m/A.
Reverse Speed (Reverse operation speed) Motor KT (spec) (Motor KT value (specification value)) Motor KT offset Motor KT high/low (Motor KT value offset + setting torque-down - setting torque-up)	Set the speed of the reverse operation. The unit is rpm. Set the KT value of the motor that is used. (Refer to the motor specifications.) The unit is N.m/A. Set the positive and negative offset value to apply to the motor KT value. This corrects for the difference between the motor torque and actual tightening torque. The unit is N.m/A.
Reverse Speed (Reverse operation speed) Motor KT (spec) (Motor KT value (specification value)) Motor KT value (specification value)) Motor KT offset Motor KT high/low (Motor KT value offset + setting torque-down - setting torque-up) Torque Coeff (Torque command correction slope coefficient)	Set the speed of the reverse operation. The unit is rpm. Set the KT value of the motor that is used. (Refer to the motor specifications.) The unit is N.m/A. Set the positive and negative offset value to apply to the motor KT value. This corrects for the difference between the motor torque and actual tightening torque. The unit is N.m/A. This correction value is applied to the torque command to stabilize it. (Perform calculation using the correction value calculation file.)
Reverse Speed (Reverse operation speed) Motor KT (spec) (Motor KT value (specification value)) Motor KT value (specification value)) Motor KT offset Motor KT high/low (Motor KT value offset + setting torque-down - setting torque-down - setting torque-up) Torque Coeff (Torque command correction slope coefficient) Torque offset Coeff (Torque command correction offset value) Motor Torque Coeff	Set the speed of the reverse operation. The unit is rpm. Set the KT value of the motor that is used. (Refer to the motor specifications.) The unit is N.m/A. Set the positive and negative offset value to apply to the motor KT value. This corrects for the difference between the motor torque and actual tightening torque. The unit is N.m/A. The unit is N.m/A. This correction value is applied to the torque command to stabilize it. (Perform calculation using the correction value calculation file.) This coefficient corrects for the difference between the motor torque

Motor Torque offset (Wait time for angle judgment in loosening operation) Reverse stand-by (Wait time for angle judgment in loosening operation) Add angle range	This setting specifies the required time, based on the angle and speed of the driver's loosening operation. The unit is ms. This is the setting range of the required time, calculated from the angle and speed of the driver's loosening operation. The unit is ms. This is the range for the angle judgment in additional tightening. The
(Additional tightening angle judgment range)	setting range is expressed in negative (-) degrees.
Reverse angle range (Loosening angle judgment range)	This is the range for the angle judgment in loosening. The setting range is expressed in negative (-) degrees.
Pattern 3, Reverse torque – Full (Torque for pattern 3 loosening operation - Negative percentage of full tightening torque)	This setting specifies the torque for the reverse rotation, in terms of negative torque relative to the full tightening torque, to prevent excessive looseness in the screw when the loosening operation in pattern 3 is performed. The unit is -%.
Torque down filter setting 1st step (Torque-down filter setting - Step 1 torque)	Set this parameter to reduce the spring-back of the bit that occurs when the servo is turned OFF after the pattern is complete. The torque limit setting is changed based on the parameters specified for steps 1, 2, and 3, in that order. The unit is %. * See Chapter 16.
Torque down filter setting 2nd step (Torque-down filter setting - Step 2 torque)	Set this parameter to reduce the spring-back of the bit that occurs when the servo is turned OFF after the pattern is complete. The torque limit setting is changed based on the parameters specified for steps 1, 2, and 3, in that order. The unit is %. * See Chapter 16.
Torque down filter setting 3rd step (Torque-down filter setting - Step 3 torque)	Set this parameter to reduce the spring-back of the bit that occurs when the servo is turned OFF after the pattern is complete. The torque limit setting is changed based on the parameters specified for steps 1, 2, and 3, in that order. The unit is %. * See Chapter 16.
Torque down filter setting Wait Time (Torque-down filter setting - Wait time)	Set this parameter to reduce the spring-back of the bit that occurs when the servo is turned OFF after the pattern is complete. The wait time specifies the amount of time to wait before applying each change to the torque limit setting. The unit is msec. * See Chapter 16.

Screen display items (buttons)

Screen	display	Description
but	ton	Description
		Save the currently configured parameters.
0.		If parameters have already been saved, the data is overwritten.
_3a	ve	When saving is complete, the [特殊設定データ保存完了] (Finished saving special setting
		data) message window is displayed.
March	Busy	[Next]/[Prev]
INext	Frev	Display the next or previous page of the [HIOS] setting screen.
Ba	ck	Return to the [Edit] screen.
		Set whether or not to use the torque-down filter.
		Select [ON] to reduce the spring-back of the bit that occurs when the servo is turned OFF
		after the pattern is complete.
		The torque limit setting is changed before the servo turns OFF upon completion of the pattern
055	O N	operation.
	UN	The torque limit setting changes based on the parameters specified for steps 1, 2, and 3, in
		that order.
		The wait time specifies the amount of time to wait before applying each change to the torque
		limit setting.
		* See Chapter 16.

8. Operation parameters

The tables in this chapter describe the parameter settings for each operation pattern, as well as the available setting ranges for the [Edit] screen and [HIOS] screen settings.

Parameter settings for each operation pattern

Operation No.	Pattern 1	Pattern 2	Pattern 3	Pattern 4		
Angle 1	Specified rotation angle	e for temporary tightenin	ng			
(Rotation angle 1: °)						
Angle 2	Not	upod	Specified rotation angle for loosening			
(Rotation angle 2: °)	NOU	useu				
Angle 3		Specified rotation		Specified rotation		
(Rotation angle 3: °)	Not used	angle for additional	Not used	angle for additional		
		tightening		tightening		
Rotation 1	Speed for temporary tig	ghtening				
(Rotation speed 1: rpm)						

		-	-	
Rotation 2		Speed for full	Speed for full	Speed for full
(Rotation speed 2: rpm)	Speed for full	tightening and	tightening and	tightening,
	tightening	additional tightening	loosening	loosening, and
				additional tightening
Trq 1 (Torque 1: N.m)	Torque for temporary t	ightening		
Trq 2 (Torque 2: N.m)	Torque for full tightenir	ng		
Trq 3 (Torque 3: N.m)	Not used	Torque for additional	Not used	Torque for additional
		tightening		tightening
Cycle TM (Cycle time: s)	Specified time for full s	et of operations of each	pattern	
Hold TM	Holding time after torq	ue-up for full tightening a	and additional tightening	
(Holding time: ms)	* See Chapter 15 "Hole	ding time"		
Torque allowance	Motor torque judgment	t range for full tightening	and additional tightening	g
(Torque judgment range:	* See Chapter 16			
±%)				
Counter	Number of times to co	unt full tightening and ad	lditional tightening torque	e judgment
(Torque judgment	* See Chapter 16			
counter)				

Parameter setting range for operation patterns

Parameter name	Description	Default value	Min. value	Max.
				value
Angle 1	Specified rotation angle for temporary tightening	7200	1	59999
(Rotation angle 1: °)	Specified rotation angle for temporary tightening			
Angle 2	Specified rotation angle for lessoning	Pattern 3: 3	1	9999
(Rotation angle 2: °)	Specified rotation angle for loosening	Pattern 4: 10		
Angle 3	Specified rotation angle for additional tightening	60	30	9999
(Rotation angle 3: °)				
Rotation 1		800	10	2800
(Rotation speed 1:	Speed for temporary tightening			
rpm)				
Rotation 2	Speed for full tightening, loosening, and additional	100	10	2800
(Rotation speed 2:				
rpm)	ugitering			
Trq 1	Torque for temporary tightening	0.300	0.300	1.300
(Torque 1: N.m)				
Trq 2	Torque for full tightening	0.300	0.300	1.300
(Torque 2: N.m)				

Trq 3	Terrus for additional tightering	3.000	0.300	1.300
(Torque 3: N.m)	lorque for additional tightening			
Cycle TM	Creatified time for full act of anarctions of each pattern	30	5	100
(Cycle time: s)	Specified time for full set of operations of each pattern			
Hold TM	Holding time after torque-up for full tightening and	150	50	500
(Holding time: ms)	additional tightening			
	* See Chapter 15 "Holding time"			
Torque allowance	Motor torque judgment range for full tightening and	5	1	99
(Torque judgment				
range: ±%)				
Counter	Setting for number of times that normal motor torque value	10	1	100
	is detected, for screw tightening judgment.			

* The minimum value is 30° because the torque-down causes the bit to spring back when the servo turns OFF after full tightening is complete.

Parameter setting range for special settings

Parameter name	Description	Default value	Min. value	Max.value
1st hold time w/rev	Holding time setting for the first full tightening in	100	50	500
(Holding time for first full	operation patterns that include reverse rotation			
tightening in operation	* See Chapter 15 "Holding time"			
patterns that include reverse				
rotation: ms)				
Tmp chat period	Period setting of one scan in the current	1	1	50
(Chattering judgment period	chattering judgment for temporary tightening			
for temporary tightening: ms)	* See Chapter 16			
Tmp chat counter	Setting for number of scans to perform in the	5	0	100
(Chattering judgment count	current chattering judgment for temporary			
for temporary tightening:	tightening			
number of times)	* See Chapter 16			
Full/Add – Specified current	Parameter setting used in the calculation of the	10	0	50
(Negative current value used	current for judgment to increase the torque-up			
for judgment of whether the	detection speed for full tightening and additional			
specified current is reached	tightening			
in full tightening and				
additional tightening: -%)				
Reverse Speed	Speed setting for reverse operation	200	1	999
(Reverse operation speed:				
rpm)				
Motor KT (spec)	KT value setting of the motor that is used	0.42	0.001	1.000
(Motor KT value: N.m/A)	(Refer to the motor specifications)			
Motor KT offset	Set the positive and negative offset value to	0	-1.000	1.000
Motor KT high/low	apply to the motor KT value.			
(Motor KT value offset	This corrects for the difference between the			
+ setting torque-down	motor torque and actual tightening torque.			
 setting torque-up) 	The unit is N.m/A.			
Torque Coeff	This correction value is applied to the torque	Factory	-32768	32767
(Torque command correction	command to stabilize it. (Perform calculation	setting		
slope coefficient)	using the correction value calculation file.)			
Torque offset Coeff	This correction value is applied to the torque	Factory	-32768	32767
(Torque command correction	command to stabilize it. (Perform calculation	setting		
offset value)	using the correction value calculation file.)			
Motor Torque Coeff	This coefficient corrects for the difference	Factory	-32768	32767
(Motor torque correction	between the motor torque and actual tightening	setting		
slope coefficient)	torque.			
Motor Torque offset	This offset value corrects for the difference	Factory	-32768	32767
(Motor torque correction	between the motor torque and actual tightening	setting		
offset value)	torque.	-		

Reverse stand-by (Wait time for angle judgment	This is the setting range of the required time, calculated from the angle and speed of the	100	0	999
in loosening operation)	driver's loosening operation. The unit is ms.			
Add angle range (Additional tightening angle judgment range)	This is the range for the angle judgment in additional tightening. The setting range is expressed in negative (-) degrees.	10	0	999
Reverse angle range (Loosening angle judgment range)	This is the range for the angle judgment in loosening. The setting range is expressed in negative (-) degrees.	10	0	999
Pattern 3, Reverse torque – Full (Torque for pattern 3 loosening operation - Negative percentage of full tightening torque)	This setting specifies the torque for the reverse rotation, as negative torque relative to the full tightening torque, to prevent excessive looseness in the screw when the loosening operation in pattern 3 is performed. The unit is -%.	0	0	100
Torque down filter setting 1st step (Torque-down filter setting - Step 1 torque)	This parameter is set to reduce the spring-back of the bit that occurs when the servo is turned OFF after the pattern is complete. The torque limit setting is changed based on the parameters specified for steps 1, 2, and 3, in that order. The unit is N.m. * See Chapter 16.	0.000	0.000	5.500
Torque down filter setting 2nd step (Torque-down filter setting - Step 2 torque)	This parameter is set to reduce the spring-back of the bit that occurs when the servo is turned OFF after the pattern is complete. The torque limit setting is changed based on the parameters specified for steps 1, 2, and 3, in that order. The unit is N.m. * See Chapter 16.	0.000	0.000	5.500
Torque down filter setting 3rd step (Torque-down filter setting - Step 3 torque)	This parameter is set to reduce the spring-back of the bit that occurs when the servo is turned OFF after the pattern is complete. The torque limit setting is changed based on the parameters specified for steps 1, 2, and 3, in that order. The unit is N.m. * See Chapter 16.	0.000	0.000	5.500
Torque down filter setting Wait Time (Torque-down filter setting - Wait time)	This parameter is set to reduce the spring-back of the bit that occurs when the servo is turned OFF after the pattern is complete. The wait time specifies the amount of time to wait before applying each change to the torque limit setting. The unit is msec. * See Chapter 16.	0	0	999

Pattern 3, Reverse torque –	This setting specifies the torque for the reverse	0	0	100
Full	rotation, as negative torque relative to the full			
(Torque for pattern 3	tightening torque, to prevent excessive			
loosening operation -	looseness in the screw when the loosening			
Negative percentage of full	operation in pattern 3 is performed.			
tightening torque)	The unit is -%.			
	This parameter is set to reduce the spring-back	0.000	0.000	5.500
Torque down filter setting	of the bit that occurs when the servo is turned			
1st step	OFF after the pattern is complete. The torque			
(Torque-down filter setting -	limit setting is changed based on the parameters			
Step 1 torque)	specified for steps 1, 2, and 3, in that order.			
	The unit is N.m. * See Chapter 16.			
	This parameter is set to reduce the spring-back	0.000	0.000	5.500
Torque down filter setting	of the bit that occurs when the servo is turned			
2nd step	OFF after the pattern is complete. The torque			
(Torque-down filter setting -	limit setting is changed based on the parameters			
Step 2 torque)	specified for steps 1, 2, and 3, in that order.			
	The unit is N.m. * See Chapter 16.			
	This parameter is set to reduce the spring-back	0.000	0.000	5.500
Torque down filter setting	of the bit that occurs when the servo is turned			
3rd step	OFF after the pattern is complete. The torque			
(Torque-down filter setting -	limit setting is changed based on the parameters			
Step 3 torque)	specified for steps 1, 2, and 3, in that order.			
	The unit is N.m. * See Chapter 16.			
	This parameter is set to reduce the spring-back	0	0	999
Torque down filter setting	of the bit that occurs when the servo is turned			
Wait Time	OFF after the pattern is complete. The wait time			
(Torque-down filter setting -	specifies the amount of time to wait before			
Wait time)	applying each change to the torque limit setting.			
	The unit is msec. * See Chapter 16.			

Operation timing charts

9. Operation pattern timing charts

This chapter describes the timing charts for each operation pattern.

Pattern 1



Pattern 2



Pattern 3



Pattern 3 operation timing chart

Pattern 4

Pattern 4 operation timing chart



10. Manual/auto mode

In manual mode, the screw tightening operation starts when the [Start] button is touched, after selecting the rotation direction ([CW]/[CCW] (Clockwise)/(Counterclockwise)) for the channel No. and pattern No. on the [Program Preview] screen. In auto mode, the screw tightening operation starts when the [Start] switch is turned ON, after selecting the rotation direction ([CW]/[CCW] (Clockwise)/(Counterclockwise)) for the channel No. and pattern No. using the external I/O switches.

Manual mode



Fig.8-1 [Program Preview] screen (1/2)



Fig.8-2 [Monitor Operate] screen

Auto mode



External I/O switches

Fig.8-3 Auto mode configuration

11. I/O

11.1 I/O allocation table

I/O input signals

Signal	Signal name	Contact	Input	Description
			signal	
IN0	Start IN	А	OFF→ON	ON: Operation starts [Enabled in auto mode]
IN1	FOR/REV switching IN	A	Level	OFF: FOR (clockwise), ON: REV (counterclockwise)
IN2	Auto/Manual switching IN	А	Level	OFF: Manual, ON: Auto
IN3	CH1 IN	А	OFF→ON	CH No. bit 0 [Enabled in auto mode]
IN4	CH2 IN	А	OFF→ON	CH No. bit 1 [Enabled in auto mode]
IN5	CH4 IN	А	OFF→ON	CH No. bit 2 [Enabled in auto mode]
IN6	CH8 IN	А	OFF→ON	CH No. bit 3 [Enabled in auto mode]
IN7	PTN1 IN	А	OFF→ON	PTN No. bit 0 [Enabled in auto mode]
IN8	PTN2 IN	А	OFF→ON	PTN No. bit 1 [Enabled in auto mode]
IN9	PTN4 IN	А	OFF→ON	PTN No. bit 2 [Enabled in auto mode]
IN10	Temporary/Full tightening switching IN	A	OFF→ON	ON: Switch to full tightening operation, when temporary tightening operation is being performed
IN11	-	-	-	-
IN12	Alarm reset IN	А	OFF→ON	ON: Reset alarm when alarm occurs
IN13	Emergency stop IN	А	OFF→ON	ON: Stop shaft rotation and generate an error
IN14	Torque judgment display clear IN	A	OFF→ON	ON: Clear the torque judgment display on the touch panel
IN15	Reverse IN	A	OFF→ON	ON: Start the reverse operation [Enabled in auto mode]

I/O output signals

Signal	Signal name	Contact	Output	Description
			signal	
OUT0	Start OUT	А	OFF→ON	ON: Operation has started
OUT1	Finish OUT	А	OFF→ON	ON: Finish operation
OUT2	FOR/REV OUT	А	Level	OFF: FOR (clockwise), ON: REV
				(counterclockwise)
OUT3	Busy OUT	А	Level	OFF: Not operating, ON: Operating
OUT4	Error 1 OUT	А	OFF→ON	ON: SVD error
OUT5	Error 2 OUT	А	OFF→ON	ON: Operation error
OUT6	Error 3 OUT	А	OFF→ON	ON: SVC error
OUT7	Error 4 OUT	А	OFF→ON	ON: Operation error (only when torque judgment is
				NG)
OUT8	Reserved			
OUT9	Reserved			
OUT10	Torque judgment OK OUT	А	OFF→ON	ON: Torque judgment is OK
OUT11				
OUT12				
OUT13				
OUT14				
OUT15				

11.2 I/O input signal reception time table

I/O input signals

Signal	Signal name	Min. reception time (msec)	Notes
IN0	Start IN	100	Received only while shaft is stopped
IN1	FOR/REV switching IN	100	Received only while shaft is stopped
IN2	Auto/Manual switching IN	100	Received only while shaft is stopped
IN3	CH1 IN		Applied when start I/O is ON
IN4	CH2 IN		Applied when start I/O is ON
IN5	CH4 IN		Applied when start I/O is ON
IN6	CH8 IN		Applied when start I/O is ON
IN7	PTN1 IN		Applied when start I/O is ON
IN8	PTN2 IN		Applied when start I/O is ON
IN9	PTN4 IN		Applied when start I/O is ON
IN10	Temporary/Full tightening	100	Received only while temporary tightening is
	switching IN		performed

■ I/O

IN11	Return to 0 position IN	100	Received only while shaft is stopped
IN12	Alarm reset IN	100	Received only while alarm occurs
IN13	Emergency stop IN	100	Always received
IN14	Torque judgment display clear IN	100	Always received
IN15	Reverse IN	100	Received only while shaft is stopped

I/O

11.3 I/O input signal sequence

Sequence of each input control signal

IN0 (Start IN)

Start enable conditions: - When in auto mode

- When CH No has been set

- When alarm reset IN (IN 12) is OFF

IN1 (FOR/REV switching IN)

Switch enable condition: When in auto mode

FOR (clockwise): Enables screw tightening direction, REV (counterclockwise): Enables screw loosening direction

IN2 (Auto/Manual switching IN)

Switches between auto mode and manual mode

IN3 (CH1 IN) to IN6 (CH8 IN)

Enable condition: When in auto mode

The channel number is selected based on the specified bit.

IN7 (PTN1 IN) to IN9 (PTN4 IN)

Enable condition: When in auto mode

The pattern number is selected based on the specified bit.

IN10 (Temporary/Full tightening switching IN)

Switches to full tightening operation, when temporary tightening operation is being performed.

IN12 (Alarm reset IN)

Alarm is reset if an alarm has occurred.

IN13 (Emergency stop IN)

If the shaft is in operation, the shaft rotation stops and an error is generated.

IN14 (Torque judgment display clear IN)

The judgment message displayed on the touch panel is cleared.

IN15 (Reverse IN)

Enable condition: When in auto mode

The screwdriver rotates in the screw loosening direction only while the signal is ON.

■ Outpu	t status signals
	OUT0 (Start OUT)
	The status of the screw tightening operation is indicated.
	The indicator lights up while the screw tightening operation is being performed.
	OUT1 (Finish OUT)
	The status of the screw tightening operation is indicated.
	The indicator lights up for 100 ms after the screw tightening operation is complete.
	OUT2 (FOR/REV OUT)
	The current clockwise/counterclockwise setting is output.
	OUT3 (Busy OUT)
	The current operation status is output.
	ON is output when shaft is in operation, and OFF is output when the shaft is stopped.
	OUT4 (Error 1 OUT)
	Output is performed when an SV-NET driver error occurs.
	OUT5 (Error 2 OUT)
	Output is performed when an operation error occurs.
	OUT6 (Error 4 OUT)
	Output is performed when an SV-NET controller error occurs.
	OUT7 (Error 8 OUT)
	Output is performed only when operation error with NG torque judgment occurs.
	OUT10 (Torque judgment OK OUT)

Output is performed only when torque judgment is OK after operation is complete.

11.4 I/O input timing charts

Timing chart for normal operations when torque judgment is OK



Timing chart for normal operations when torque judgment is NG

Timing chart when emergency stop signal is input

Message window

12. Message window

The message window is displayed when data loading or saving is complete, and for events such as the torque judgment after screw tightening.

To close the message window, touch the top part of the window or turn ON the IN14 signal of the external I/O.

Displayed messages

Fig.12-1 [Finished loading data] message window

Message	
Torque OK	
1. 234 N. r	n

Fig.12-2 [Torque judgment OK] message window (Pattern 1)

Fig.12-3 [Torque no good] (Torque judgment NG) message window (Pattern 1)

[Torque less than set] (Below motor torque setting)

Fig.12-4 [Torque judgment OK, additional tightening angle judgment OK] message window (Pattern 2)

Message window

Fig.12-5 [Torque judgment NG, additional tightening angle judgment OK] message window (Pattern 2)

Fig.12-6 [Torque judgment OK, additional tightening angle judgment NG] message window (Pattern 2)

Fig.12-7 [Below additional tightening torque setting, additional tightening angle judgment OK] message window (Pattern 2)

Fig.12-8 [Torque judgment OK, loosening angle judgment OK] message window (Pattern 3)

Fig.12-9 [Torque judgment NG, loosening angle judgment OK] message window (Pattern 3)

Fig.12-10 [Torque judgment OK, loosening angle judgment NG] message window (Pattern 3)

Fig.12-11 [Torque judgment NG, loosening angle judgment OK] message window (Pattern 3)

Fig.12-12 [Torque judgment OK, additional tightening angle judgment OK, loosening angle OK] message window (Pattern 4)

Fig.12-13 [Torque judgment NG, additional tightening angle judgment OK, loosening angle OK] message window (Pattern 4)

Message window

Fig.12-14 [Torque judgment OK, loosening angle judgment OK, additional tightening angle NG] message window (Pattern 4)

Fig.12-15 [Torque judgment NG, additional tightening angle judgment OK, loosening angle OK] message window (Pattern 4)

Fig.12-16 [Torque judgment OK, additional tightening angle judgment OK, loosening angle NG] message window (Pattern 4)

Fig.12-17 [特殊設定データ保存完了] (Finished saving special setting data) message window

Message window

Message list

Message	Description
Data loaded	Finished loading the parameter settings.
Data saved	Finished saving the parameter settings.
特殊設定データ保存完了	Finished saving the parameters of special settings.
(Finished saving special setting data)	
Torque OK	The torque detection value is within the setting range.
(Torque judgment OK)	* The torque is not displayed if the judgment count is set to 0.
Torque no good	The motor torque detection value is above the upper setting limit.
Torque more than set	
(Torque judgment NG -	
Above motor torque setting)	
Torque no good	The motor torque detection value is below the lower setting limit.
Torque less than set	
(Torque judgment NG -	
Below motor torque setting)	
No torque judgment	Displayed when screw is rotated to specified angle before torque-up is detected,
	when performing additional tightening to specified angle.
	Only the most recent motor torque value is displayed.
Additional tightening angle	When the additional tightening operation is performed in patterns 2 and 4, the
	value specified for [Angle 3] (Rotation angle 3) on the touch panel display is used
	to judge the angle of rotation after the torque-up of additional tightening.
Loosening angle	When the loosening operation is performed in patterns 3 and 4, the value
	specified for [Angle 2] (Rotation angle 2) on the touch panel display is used to
	judge the angle of rotation in the loosening operation.

System settings

13. System settings

On the touch panel VT3 system settings screen, you can change the password and set whether or not a sound is emitted when buttons are touched.

In addition, the system settings screen can be used to monitor the device, by checking the total number of screw tightening OK judgments.

Displaying the system settings screen

To display the system settings screen on the touch panel, first place a finger on the screen where there are no other buttons for at least 3 seconds, then remove your finger for less than 1 second and touch the top right edge of the touch panel screen. * For more information, refer to Chapter 9 "Special operations screen" in the "VT3_Hardware.pdf".

Checking the screw tightening OK judgment count

You can check the total number of screw tightening OK judgments by viewing the MW07FE and MW07FF built-in touch panel devices in [デバイスモニタ] (Device monitor) on the system settings screen.

MW07FE: The count increases by 1 for each 10,000 OK judgments. (Unit: 10,000 times)

MW07FF: The count increases by 1 for each OK judgment, and the count is reset to 0 when the count reaches 10,000. (Unit: 1 time)

* For more information, refer to Chapter 5 "System modes" in the "VT3_Hardware.pdf".

Note: When TP project data is transferred, all device values are reset (judgment counts are set to 0).

Checking the total number of screw tightening OK judgments

[Total No. of fastened Counter] (Total count monitor for screw tightening OK judgments - OK judgment counter)

■ You can check the total number of times that the screw tightening OK judgment has been counted.

Button touch operations

14. Button touch operations

The [Rev], [Manual], [Auto], [CW], [CCW], [Torque down filter setting] buttons have an ON delay of 0.5 second.

The buttons do not respond unless they are touched for at least 0.5 second.

The [Load], [Save], [Start], [Stop], [Error Reset], and [HIOS] buttons have an OFF delay of 0.5 second.

When these buttons are pressed, other buttons do not respond for 0.5 second.

Holding time

15. Holding time

- Holding time setting
- The holding time setting range is from a minimum of 50 msec to a maximum of 500 msec.
- Each screw tightening judgment takes several msec, so when the number of judgments is increased, the actual torque holding time may become longer than the setting, depending on the holding time value that is specified. When increasing the number of judgments, it is also necessary to specify a longer holding time.
- When using chattering judgment for temporary tightening, a higher temporary tightening speed results in a longer torque holding time.
- When using chattering judgment for temporary tightening, a smaller difference between the temporary tightening torque and full tightening torque results in a longer torque holding time.

Detailed pattern diagrams

16. Detailed pattern diagrams

Chattering judgment

Details of chattering judgment

When the torque specified for temporary tightening is exceeded, the current is consecutively scanned the specified number of times during the specified chattering judgment period (msec), and the next operation is performed only if all judgments are OK.

The full tightening operation is not performed if the current falls below the temporary tightening current even one time.

Detection may be prevented if the screw becomes caught or if there are fluctuations in the current.

Detailed pattern diagrams

Screw tightening judgment

Details of screw tightening judgment

Each judgment determines whether the current is within the specified judgment range, above the upper limit, or below the lower limit, and the counter in the parameter settings is updated with the number of judgments that are counted.

Torque-down filter

Details of torque-down filter

Alarms

17. Alarms

If a device error occurs or the results of the screw tightening judgment are NG, the error No. is displayed on the [Operate] screen, and the touch panel screen flashes to indicate that an error has occurred.

To cancel the alarm, remove the cause of the error, then touch the [Error Reset] button on the [Operate] screen or [Monitor Operate] screen, or turn ON the IN12 signal of the external I/O. The details for each error No. are shown in the error list below.

17.1 Error list (motor driver errors)

Error No.	Name	Description	Status	Cause	Solution
11	Over Current	Error or	Occurs only when	Driver malfunction	Replace driver
		excessive	power is turned ON		
		current in	Occurs when servo is	Short-circuit in motor	Check motor wiring
		power drive	turned ON	wiring	
				Short-circuit in motor	Replace motor
				winding	
				Driver failure	Replace driver
			Occurs when	Poor driver adjustment	Lower the gain
			accelerating/decelera	Driver failure	Replace driver
			ting		
21	Over Load	Overload	Motor vibrates when	Poor adjustment	Readjust the gain
		alarm	servo is turned ON or		
			while in operation		
			Occurs when	Acceleration/deceleration	Reduce the
			accelerating/decelera	speed is too high	acceleration/deceleration
			ting		speed
			Occurs at a particular	The load torque is too	Check the mechanical
			rotation speed	high	parts/
					Increase the motor size
			Occurs when servo is	Motor wiring	Check motor wiring
			turned ON		
31	Over Speed	Speed alarm	Occurs while in	Speed limit is exceeded	Readjust the gain
			operation		
41	Counter	Multi-rotation	Occurs while motor is	Multi-rotation data of	Set the amount of
	Overflow	error	rotating	resolver exceeded the	movement from the origin
				specified value	to within 7,000,000 hex
					count/
					Initialize the sensor/
					Enable unlimited rotation

■ Alarms

42	Excess	Value of	Occurs at pulse	Pulse was input without	Check the servo ON
	position	deviation	command input	turning servo ON	signal
	deviation	counter		The F-LMT and R-LMT	Check the wiring and
		exceeded the		signals are not input or	settings
		specified		configured	
		value	Occurs when	Acceleration/deceleration	Reduce the
			accelerating/decelera	speed is too high	acceleration/deceleration
			ting		speed

Error list (motor driver errors)

Error No.	Name	Description	Status	Cause	Solution
51	Over heat	Abnormal	Occurs while in	Frequent use while	Relax the operating
		temperature	operation	overloaded	conditions
		of power		Ambient temperature is	Install a fan or other
		drive was		high	device to improve heat
		detected			dissipation
61	Sensor Error	Sensor error	When power is	Detected small amplitude	Turn up the sensor
			turned ON	of resolver signal	excitation voltage one step
62				Detected excessively	Turn down the sensor
				large amplitude of	excitation voltage one step
				resolver signal	
71	Over Voltage	Excess drive	Occurs while in	Insufficient regeneration	Insufficient power supply
		voltage	operation	ability	capacity:
					Add regeneration
					protection circuit to power
					supply/
					Insufficient regeneration
					protection ability:
					Reduce the deceleration
					speed
			Occurs when power	If detected when power is	Change the driver
			is turned ON	turned ON, the voltage	
				specifications are not	
				suitable.	
				Driver failure	Replace driver
			Sometimes detected	Driver detects voltage of	Increase the value of
			when using	regeneration protection	ID205 "Excess voltage

			regeneration unit TA8413 with 48 V power supply	operation	error detection voltage" (upper limit: 65 V)
72	Voltage Down	Low drive voltage	During operation	Insufficient power supply capacity	Add regeneration protection circuit to power
				Disconnection in drive power supply line	зарру
			When power is turned ON	Disconnection in drive power supply line	Check wiring
91	Flash Memory Error	Non-volatile memory read error	When power is turned ON	Failure of non-volatile memory or CPU in integrated circuit	Replace driver
92		Non-volatile memory write error	When writing the parameters		

Error list (motor driver errors)

Error No.	Name	Description	Status	Cause	Solution
98	Hardware	CPU error	Occurs while in	Incorrect operation due to	Install a noise filter
	Error		operation	noise	
			When power is	Driver malfunction	Replace driver
			turned ON		
99	Parameters	Parameter	When writing the	Abnormal values when	Check the values of the
	Error	error	parameters	writing the parameters to	parameter settings that
				non-volatile memory	were changed
				(writing is not performed)	

■ Alarms

17.2 Error list (operation errors)

Error No.	Name	Description	Status	Cause	Solution
100	Screw	Screw	Emergency stop	Emergency stop button	Check the device status
	tightening	tightening	button was pressed	was pressed	and perform error reset
	operation	operation	Screw tightening time	The time of the operation	Check the device status
	error	error	was exceeded	exceeded the time set for	and perform error reset
				the screw tightening cycle	
102	Torque	Torque	Torque judgment	Detected a value outside	Check the device status
	judgment NG	judgment NG	result is NG	the upper or lower limit of	and perform error reset
				the range, in the screw	
				tightening torque	
				judgment	
103	I/O input NG	External I/O	The channel No. and	Input error	Perform error reset, then
		CH No and	pattern No. from the		enter the external I/O
		external I/O	external I/O have not		channel No. and pattern
		PTN No entry	been selected		No.
		omission			
104	Angle	Screw	Error in additional	Occurs if the angle does	Specify the angle again
	judgment NG	tightening	tightening angle or	not reach the angle	when pattern 2, 3, or 4 is
		operation	loosening angle	specified when pattern 2,	set
		error		3, or 4 is set	

17.3 Error list (SVC errors)

Error No.	Name	Description	Status	Cause	Solution
200	SVC error	SVC error	Error occurred in SV-	Controller program error,	Refer to the user's manual
+ SVC			NET controller.	etc.	for the SV-NET controller.
error			The error No. is 200		
No.			+ the SVC error No.		